

Introducing Flex Power!

- 460 volt is preferred operating voltage
- Allows Vector units to operate on 208/230 volts
- Full capacity at 230 volts
- Field installed “step-up” transformer

